

Updated: August 31, 2020

FEMAP

PL8514778: Simcenter Femap Node-lock License Available for Users Working From Home - EXTENDED Until 9/30/2020

Dear Simcenter Femap Customer,

Due to COVID-19, Siemens DISW understands many Femap users will be required to work from home for an unspecified amount of time. While users of floating licenses may be able to remote desktop into their Windows machines in the office to use Femap via their organization's VPN or other protocol, this is not possible for users licensed via dongle/security key (i.e., a node-lock license).

Because of this limitation, Siemens DISW has made a special node-lock license file available via the Support Center site for anyone who needs to use Femap on their Windows machine at home or via Remote Desktop over VPN or other protocol for any reason. If using on a home Windows machine, each user who would like to use this file will be required to download the appropriate version of Femap they need from Support Center, then follow the instructions below during installation. Typically, the user should be downloading and installing the same version of Femap they are using at the office so models created at home can be opened after returning to the office.

Once Femap has been installed as described in the "Installation" section below or to allow use of an already installed version of Femap on a machine in the office

currently licensed by a dongle/security key via Remote Desktop, simply take the license file found here:

[Node-Lock License File](#)

...and place it into the Femap Installation directory. For instance, for Femap v2020.2, you would want to place the license file in the "Femap 2020.2" directory, while for FEMAP v12.0.1, you would want to place the license file in the "FEMAPv1201" directory.

To convert an already installed Femap from using a dongle/security key license to be able to use this license file, please see the "Updating Existing Dongle Licensing" section below.

This license is good until September 30th, 2020. As was done with the original COVID-19 node-lock license file, as September 30th approaches Siemens DISW will reevaluate the situation. If needed, Siemens DISW will post an updated license file good for an additional time period and will continue doing so as long as Siemens DISW feels it is required.

PLEASE NOTE: This license cannot be used to run SOL 601 or SOL 701 with Simcenter Nastran. If you are currently licensed to use these products and need a license which allows you to use these products while working from home, please contact Customer Support.

=====

Installation:

=====



In order to download Femap and the "Node-lock license file", you will need a Webkey. Femap customers can use Webkey for both licensing support and product technical support.

If you do not have a Webkey, you can obtain one here:

<https://support.sw.siemens.com/register>

Click on the "Create Account" button, then provide the required information.

Please note, to obtain a Webkey, you MUST have the following information:

- Your Installation ID (SoldTo)
- Webkey Access Code

Your Installation ID is directly under the "SoldTo" information on your shipping order. For dongle-based Femap customers, your Webkey Access code is the unique portion of your Femap serial number, i.e. 3H-NT-1234, which is displayed in your current Femap in the Help - About dialog box, for this license as 1000-3H-NT-1234, with the version information at the beginning of the serial number removed.

Once a Webkey has been obtained, it is now time to download the software and the license file. Because different users will require different versions of Femap, it is probably best to manually navigate to where multiple versions of Femap are available to download via Support Center. To do this, use this link:

<https://support.sw.siemens.com/>

First, choose Simcenter Femap from either the "Products" drop-down at the top of

the page or choose the "View Product Center" button on the Simcenter Femap block in the "My Products" section. Next, click the "Downloads" block. At this point, select the version of Femap you would like to download. To reduce the number of items in the list of downloads, use the "Select a Version" drop-down control at the top of the list.

Please Note: Unless required, Siemens DISW recommends that if you are installing a version of:

2020.2 - install 2020.2 MP2

2020.1 - install 2020.1 MP2

2019.1 - install 2019.1 MP1

12.0.x - install 12.0.1

11.4.x - install 11.4.2

11.3.x - install 11.3.2

After downloading the zip file for the desired version of Femap, unzip to a temporary location. The zip file contains an exact copy of the Femap DVD for the version which you have downloaded. Run setup.exe using "Run as Administrator" to install Femap.

Click "Yes", "OK", and/or "Next" on all installation screens until arriving at the "Select Features" screen. At this point, select which features of Femap you would like to install, then click "Next".

You should now be on the "Select FEMAP GUI Language" screen, so select your language of choice, then click "Next".

VERY IMPORTANT!!! You should now be on the "Setup Type" screen which states "Select Licensing Method". While it may seem counter-intuitive, in order to use the

Node-lock license file is available via Support Center, you MUST select the "Network Client – FLEXlm" option on this screen. If you do not, Femap will not be able to find the license file. Once selected, click "Next" which will begin installing Femap.

Once installation is complete, place the license file you have downloaded from Support Center into the Femap Installation directory. For instance, for Femap v2020.2, you would want to place the license file in the "Femap 2020.2" directory, while for FEMAP 12.0.1, you would place this file into "FEMAPv1201".

=====

Updating Existing Dongle Licensing:

=====

To convert an existing Femap installation which is currently licensed via a dongle/security key to be able to use this license file, Femap must be instructed to use network licensing instead. To do this, follow these steps:

1. Exit all open instances of Femap completely
 2. Browse to the installation directory of the version of Femap you would like to convert licensing methods (for Femap 2020.2, it is "Femap 2020.2", while for FEMAP 12 it is "FEMAPv12")
 3. In the Femap installation directory, locate "go_network.bat", then double-click it to change licensing methods
 4. Place the license file downloaded from Support Center into the Femap installation directory
 5. Open Femap and you should now be licensed via the license file downloaded from Support Center
-

To return Femap to being licensed by a dongle/security key, follow these steps:

1. Exit all open instances of Femap completely
2. Browse to the installation directory of the version of Femap you would like to convert licensing methods
3. In the Femap installation directory, locate "go_dongle.bat", then double-click it to change licensing methods
4. Open Femap and you should now be licensed via the dongle/security key

If any questions arise regarding this field bulletin, Siemens DI Software Customer Support may be contacted at:

All USA & Canada (800) 955-0000

If you are outside the United States and Canada, any questions regarding this or any other SFB should be directed to your local support office, quoting the SFB number
